

FIG. 1




Fig. 2




Fig. 3

COMMAND NODE

0	CONTROL FLAGS	320	346
1	BUFFER ADDRESS BYTE 0	322	
2	BUFFER ADDRESS BYTE 1		
3	TRANSFER LENGTH BYTE 0	324	
4	TRANSFER LENGTH BYTE 1		
5	START LBA BYTE 0	326	
6	START LBA BYTE 1		
7	START LBA BYTE 3		
8	START LBA BYTE 3		
9	START PHYSICAL CYLINDER BYTE 0	328	
10	START PHYSICAL CYLINDER BYTE 1		
11	START PHYSICAL HEAD	330	
12	START PHYSICAL SECTOR/STARTING WEDGE BYTE 0	332	
13	START PHYSICAL SECTOR/STARTING WEDGE BYTE 1		
14	NOT USED		
15	NOT USED		
16	NOT USED		
17	NOT USED		
18	NOT USED		
19	NOT USED		
20	NOT USED		
21	NOT USED		
22	END PHYSICAL CYLINDER BYTE 0	334	
23	END PHYSICAL CYLINDER BYTE 1		
24	END PHYSICAL HEAD	336	
25	END PHYSICAL SECTOR/STARTING WEDGE BYTE 0	338	
26	END PHYSICAL SECTOR/STARTING WEDGE BYTE 1		
27	AGE	340	
28	PREVIOUS LINK BYTE 0	342	
29	PREVIOUS LINK BYTE 1		
30	NEXT LINK BYTE 0	344	
31	NEXT LINK BYTE 1		

Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig. 10